

North Country Door recommendations to calculate door sizes:

First: Select Your Hardware Before Ordering!

¼ overlay using Euro hinges – add ½ inch to the door opening

½ overlay using Euro hinges – add 1 inch to the door opening

Using standard hinges – full overlay – add ½ inch to the width and height of door opening.

Inset doors – recommend leaving 1/8 inch all around the door.

Our boring for the 35mm European cup hinge is placed 3 ½” down from the top of the door and again up from the bottom of the door 3 ½” to the center of the bore. It is placed 1/8 inch from the edge of the door. (If you need something different – we can usually accommodate your needs)....On tall doors we can add additional bore(s) if wanted for stability reasons.

NCD has given these recommendation to calculate sizes for my products, however, I understand that it is my responsibility to be sure that these are the sizes I want and what works for my project. NCD guarantees they will give me the wood species, specs of products, and the sizes that I have signed and confirmed for.

Signature and Date